



**NOTES:**

- 1: CONCRETE ANCHORS ARE RECOMMENDED FOR SLOPES GREATER THAN OR EQUAL TO 20%.
- 2: ANCHORS SHALL BE INSTALLED AT EACH JOINT.
- 3: PIPE SHALL BE INSTALLED USING CLASS I OR CLASS II BACKFILL COMPACTED TO 95% SPD, IN ACCORDANCE WITH PRINSCO STORMWATER INSTALLATION GUIDE TN-2-207.
- 4: ANCHOR DESIGNS MAY VARY; THE PROJECT ENGINEER SHALL SPECIFY THE ANCHOR DESIGN BASED ON ANTICIPATED LOADING AND SOIL CONDITIONS.
- 5: A SCREEN OR NONOVEN GEOTEXTILE COVERING THE 4" GOLDFLO WEEP HOLE IS OPTIONAL.

THIS DETAIL DEPICTS RECOMMENDED INSTALLATION PRACTICES AND IS NOT INTENDED TO SUPERSEDE ANY NATIONAL, STATE OR LOCAL SPECIFICATIONS. PRINSCO BEARS NO RESPONSIBILITY FOR ANY ALTERATIONS, REVISION AND/OR DEVIATION FROM THIS STANDARD DETAIL. PRINSCO HAS NOT PERFORMED ANY ENGINEERING OR DESIGN SERVICE FOR THIS PROJECT. THE DESIGN ENGINEER SHALL REVIEW THESE DETAILS PRIOR TO CONSTRUCTION TO VERIFY SUITABILITY. © PRINSCO, INC.



1717 16TH ST. NE  
WILLMAR, MN 56201  
www.prinSCO.com

TITLE: HP PIPE - INSTALLATION - STEEP SLOPE PIPE ANCHORING			
DRAWN BY:	BJE	DATE:	15-Jun-26
SCALE:	NTS	SHEET:	1 OF 1
			DRAWING NUMBER: D-2-164